



JARD Trigger System for CZ® 457 Installation Guide



Tools Needed:

1. T25 torx
2. Pick or small screwdriver
3. 3/32nds punch



3149 Nest Ave. – Sheldon, IA 51201

Phone: 712-324-7409

Email: support@jardinc – www.jardinc.com

Step 1:

Remove the magazine and inspect the chamber to ensure the firearm is unloaded.



Step 2:

Remove the bolt.



Step 3:

Using the T25 torx (tool #1), remove the two action screws and the trigger mounting screw. Then, remove the stock.



Note: The long screw is the back screw.



Step 4:

Next, take the pick (tool #2) and remove the small e-clip.

Note: There is an e-clip on each side. Only remove one side's e-clip.



Step 5: Take the punch (tool #3) and use it to remove the trigger mounting pin.



Step 6: Remove the two pieces of the factory trigger.

Note: The sear is contained in JARD assembly.

Step 7:
Insert JARD trigger mounting pin.



Step 8:
Install the e-clip.



Step 9:
Using the T25 torx (tool #1), insert the mounting screw.





Step 10:

Put stock back in place and re-insert the action screws

Reminder: Long screw in back, short screw in front



Step 11: Insert the bolt and perform function and safety checks.



JARD, Inc.

3149 Nest Ave. – Sheldon, IA 51201

Phone: 712-324-7409 – Email: support@jardinc.com

www.jardinc.com

