



Savage Model 25

Operators Instruction Manual



3149 Nest Ave. – Sheldon, IA 51201
Phone: 712-324-7409
Email: jardusa@live.com – www.jardinc.com

WARNING

This firearm is intended for use only by experienced competitive shooters and professionals. You must take responsibility for your own actions. We will not be responsible for any loss, injury, or death resulting from the use or misuse of this product.

The handling and use of firearm bears with a certain unavoidable risks, like sky diving and rock climbing. If you are not willing to accept responsibility for your own actions, guns are not for you.

The use of any custom parts or modifications may void any warranty from the manufacturer of your firearm.

Returns will not be accepted on any parts that have been modified.

If you do not have a thorough understanding of the Savage Model 25 Trigger Assembly and the purpose and function of all the parts, do not attempt to install this system. Have it installed by an experienced gunsmith.

JARD Savage Model 25 Replacement Trigger

Installation

1. Verify the gun is unloaded and remove the stock from the receiver.
2. Remove the mounting screws (2) attaching the trigger housing to the receiver
3. Remove factory trigger assembly and install the JARD trigger assembly.
4. Install factory mounting screws and stock.


Trigger Adjustment

Read directions completely before beginning procedure.

Your JARD trigger system comes adjusted from the factory and should be a replacement only procedure. However should decide to modify the factory settings, below are some guidelines.

1. Verify the gun is unloaded and remove the stock from the receiver.
2. To adjust the sear engagement screw (6), turn the screw counterclockwise several turns and close the bolt leaving the action cocked. Switch the safety selector to the fire position. Slowly turn the screw clockwise until the sear is released. Turn the screw slightly back counterclockwise until safe sear engagement is achieved (approx. ¼ turn) (Note: There must be sufficient sear engagement to allow reliable safety function.)
3. Check functioning of the trigger by slamming the bolt (closing it sharply) several times. If the sear is not released when closing sharply, it may be possible to adjust for less sear engagement. However, if the sear is released, more sear engagement and/or pull weight increase is needed.
4. Once the sear engagement has been successfully set, the safety can be adjusted. With the action cocked, switch the safety selector to the safe position. If the safety cannot be engaged, the safety screw (7) must be turned counterclockwise to allow the safety to move back. Once the safety is on the on position, turn the safety screw clockwise until it engages the safety. With the safety on and the action cocked, there should be no movement in the trigger and the selector should move back and forth freely.
5. Install the receiver into the stock and preform function and safety checks.

Savage Model 25 Assembly Parts Breakdown List



ITEM NO.	PART NO.	DESCRIPTION	QTY.
1	3469	Trigger Housing	1
2	3467	Trigger	1
3	3468	Sear	1
4	3470	Safety Plate	1
5	1231	Safety Knob	1
6	1160	Sear Adj. Screw	1
7	1125	Safety Screw	1
8	2764	Detent	1
9	1452	Retaining Pin	2
10	1254	E-Clip	2
11	1238	Dowel Pin	2
12	1127 1128 1129	Trigger Return Spring 5 oz 6 oz 8 oz	1

Jard, Inc.

3149 Nest Ave. – Sheldon, IA 51201

Phone: 712-324-7409 – Email: jardusa@live.com

www.jardinc.com